

Installation Instructions

CTS-V Rear Brake w/ E-Brake Conversion (10 Bolt GM)

001 - Remove Wheel, Brake Caliper, Caliper Bracket, Brake Hose, and Differential Cover. Push axle toward the differential and remove C-Clip. Remove Axle, Brake Bracket, and Parking Brake Cable.



002 – Install new CTS-V Brake Brackets with new Hardware.



003 - Install new CTS-V Parking Brake Assemblies with new hardware.



004 – Install new CTS-V Parking Brake Cable Brackets, Parking Brake Conversion Cables, and Stainless Steel Brake Hoses. Latch the Parking Brake Cables onto the Parking Brake Levers. Reinstall the Axles, C-Clips*, and the Differential Cover.

*Make sure the C-Clips fully seat in the Differential.



005 – Install Rotors, Calipers, and Brake Pads. Connect the new Stainless Steel Brake Hose to the Caliper with new Copper Bushings and Caliper Bolt. Bleed Rear Calipers and Reinstall Wheel.

