


ATTACH TERMINAL TO MUSIC WIRE & PULL THROUGH COLUMN UNTIL SLACK IS REMOVED

INSTALL LEVER BY ALIGNING TANG AND PUSH STRAIGHT IN UNTIL SEATED IN SPRING RETAINER



POSITION COLUMN AS FOLLOWS:

- 1. SHIFT LEVER IN LOW POSITION**
- 2. TURN SIGNAL SWITCH IN RIGHT TURN POSITION**
- 3. FOR TILT COLUMN INSTALLATION, COLUMN IS TO BE IN FULL UP POSITION**